
Barrier Films and Adhesives for OLED Solid State Lighting

Fred B. McCormick - 1/29/14 - DOE SSL Workshop - Tampa, FL





3M Vacuum Processed Barrier Films




Top coat polymer

Oxide 1

Base polymer

Substrate

- Multilayer Construction
 - Substrate
 - Polymer layers
 - Oxide layers
- Oxide provides barrier
 - High transparency & clarity
 - Low haze
 - Good flexibility
- Tortuous path from Multi-dyads
 - Can increase barrier performance:





Initial Product Offerings

FTB3-50 and FTB3-125 (Commercially Available)

"Flexible Transparent Barrier"

- WVTR (g/m²-day)
 - $\leq 1 \times 10^{-3}$ warranted (Mocon Permatran 700)
 - 10⁻⁴ to 10⁻⁵ typical (Ca test, HTO test)
 - Can work for OLEDs with thin film encapsulation
- PET substrate used in current commercial products
 - PET OK for backside of OLED displays and OLED SSL
 - OLED displays may require non-birefringent barriers

FTB3-50 and FTB3-125

1 103-30 and 1 103-123
Premask
Polymer
Barrier Oxide
Polymer
2 or 5 mil PET

FTBA-25 (Samples Available)

"Flexible Transparent Barrier Adhesive"

- 25 μm standard thickness, ~10-50 μm also possible
- 2-4 g/m²-day bulk adhesive WVTR

FTBA-25

Release Liner
Barrier Adhesive
Release Liner

FTB-50a and FTB3-125a (Samples Available)

Adhesive laminated to barrier film

FTB3-50a and FTB3-125a

Release Liner
Barrier Adhesive
Polymer
Barrier Oxide
Polymer
2 or 5 mil PET



"OLED Grade" Barriers (In Development)

"FTB6-125L" (Samples Available)

- Laminate two FTB3-50 films together with FTBA-25
 - 10⁻⁶ to 10⁻⁷ in preliminary Ca WVTR testing
 - Relatively thick construction

Polymer	
Barrier Oxide	
Polymer	
Substrate	
Adhesive	
Polymer	
Barrier Oxide	
Polymer	
Substrate	

Adhesive
Polymer
Barrier Oxide
Polymer
Substrate
Adhesive
Polymer
Barrier Oxide
Polymer
Substrate


- Long term target coat multiple dyads directly
 - Thinner and simpler construction
 - Optimizing process conditions


Polymer
Barrier Oxide
Polymer
Barrier Oxide
Polymer
Substrate



3M's Version of the Calcium Test

- 1) Deposit 1000Å Ca as a 44 x 144 mm pad on a 50 x 150 mm glass slide or four 7 x 7 mm pads on a 50 x 50 mm glass slide
- 2) Encapsulate with barrier film and barrier adhesive
- 3) Measure optical density at T₀ using flatbed optical scanner (transmission mode)
- 4) Place in 60C/90%RH chamber and periodically remove for scanning
- 5) Use image analysis software (Aphelion) to track
 - > Optical density,
 - ➤ Moisture edge ingress
 - > Point defects
 - > Scratches & other macroscopic defects
 - ➤ Barrier uniformity











Ca Test Examples – WVTR & Edge Ingress







Suggested DOE Research Areas

- Defects
 - Elimination, reduction, rapid detection
- WVTR measurement techniques
 - Faster methods with lower detection limits
- Edge ingress & edge sealing
- Hybrid encapsulation systems
 - Barrier films & adhesives coupled with thin film encapsulation
- Lower cost substrates
- Electrical interconnects for flexible devices
- Large area transparent conductors
- Environmentally robust OLED architectures

Important Notice

3M does on occasion provide internal 3M test data as a service to our customers. 3M does not certify the accuracy or validity of this information and 3M is not responsible for Customer's interpretation of or use or misuse of the provided information. For example, Customers should not use this information for business purposes, including but not limited to setting test criteria, developing a specification or evidence of meeting a specification, or as a basis for determining if a product is fit for a particular application or will have particular attributes. Product attribute claims should not be based on this information.

The information provided is made available on an "as is" basis. 3M makes no warranty, express or implied, related to this information. 3M shall not be liable for any incidental, special, or consequential damages relating to the use or inability to use this information, regardless of the legal theory asserted.

