

# Charge Balance in OLEDs: Optimization of Transport Materials

DOE SSL R&D Workshop

Tampa, FL

January 29, 2014




All references to “Merck” refer to Merck KGaA, Darmstadt, Germany.  
In North America Merck operates under the name EMD.

# Transport Materials are Critical Components in High-Performance OLED Devices

- Enable key performance characteristics
  - Low voltage
  - Long lifetime
- Voltage and lifetime typically trade-off in devices. Charge balance is key to maximize both properties.
- Reducing drive voltage to  $\sim 3\text{V}$  is a challenge. Can this be done with a single material or is p/n doping the best approach?

# Trade-off between Lifetime and Efficiency



*E. Böhm, C. Pflumm, F. Voges, M. Flämmich, H. Heil, A. Büsing, A. Parham, R. Fortte, T. Mujica, IDW'09, OLED1-2, p.431 (2009).*

**This behavior is well-established, particularly for fluorescent blue OLEDs**

# Tuning Charge Balance with Mixed Host


## Mixed host systems

Two host components are used to adjust charge balance

- Lifetime improvement by a factor of two
- Low roll-off
- Low voltage

compared to single host system

## Emission Zone



**e-type TMM** shifts luminance zone to the HTM layer

**h-type TMM** shifts luminance zone to the ETM layer


**Mixed or bipolar TMM** can lead to a luminance zone in the middle of the EML

**Host materials (TMMs) are key to optimize & control charge balance in the device**

# Tuning Charge Balance with Mixed Host

## Requirements


- Balance can be tuned by adjusting the host mixing ratio: e-type TMM + h-type TMM
- Customized for customer device



- Merck addresses triplet Green, Yellow & Red OLEDs

## Balance Adjustment



- Example : combination of
- h-type (material A and B) with
  - e-type (material 1 and 2)



e-type:	h-type:	A	B
1	Best co-host ratio	>10%	47%
	LT50 [h]	100%	180%
	Eff. [cd/A]	100%	120%
	V [V]	3.8	3.9
2	Best co-host ratio	32%	>63%
	LT50 [h]	150%	110%
	Eff. [cd/A]	120%	105%
	V [V]	3.7	4.5


# Charge Balance Optimization through the Introduction of an HBL

With a hole-rich EML mixture, we need to adjust the charge balance by introducing an HBL



Lifetime and efficiency are further improved with the introduction of an HBL


# A Winning Strategy Leading to Impressive Results in Solution Processed Devices



CIE x,y	Eff [cd/A] @1000cd/m²	Voltage [V] @1000cd/m²	EQE [%] @1000cd/m²	Est. LT50 [h] @1000cd/m²
0.33, 0.63	81.3	4.7	21.8	320.000

**Record efficiency & LT in phosphorescent green with more hole-injecting HTL.  
The gap between solution and vapor processing is closed?**

# Charge Balance Optimization



Adding more electron transporting materials to EML mixtures results in lower voltage, but reduced lifetime

→ Not enough holes to counterbalance the electrons!

For a given EML mixture, vary the hole injection properties of the HTL.


→ HTL with strong hole injection can improve voltage and lifetime simultaneously!

**Introduction of more hole-injecting transport layers significantly improves lifetime**



# Performance Progress – Solution Processing

Triplet Green




evaporated



solution-processed

Triplet Red



Huge performance improvement with new materials in optimized devices

# Novel HTMs with Electron Blocking Capability

Cathode	HTM	CIE x/y	Efficiency [cd/A] @ 1000 cd/m <sup>2</sup>	Voltage [V] @ 1000 cd/cm <sup>2</sup>	EQE [%] @ 2000 cd/m <sup>2</sup>	LT <sub>50</sub> [h] @ 1000 cd/m <sup>2</sup> (based on n=2)
ETL						
S-Blue EML	HTM-081	0.14/0.14	9.2	4.1	8.4	21 000
<b>New HTM</b>	<b>New HTM</b>	<b>0.13/0.14</b>	<b>13.2</b>	<b>4.1</b>	<b>11.6</b>	<b>44 000</b>
HTM-081						
HIL						
ITO						

→ Further improvement compared to HTM-081 based device

- EMD / Merck have developed a variety of new HTMs, for use as hole transporting layers with high triplet level & electron blocking capability
- New stack configurations provide excellent lifetime, efficiency and voltage for fluorescent & phosphorescent devices

# EMD: OLED Solution Provider

R&D experts

M&S experts

~1,400 patents

## Commitment to OLED

- New investment of MRC Darmstadt (2009), extensions in 2013 and 2014
- Extension of OLED scale-up and production in DA in 2013
- Setup of OLED formulation in Germany and UK 2012/13
- Continuous Investment in laboratories in Korea, Taiwan and Japan

Germany (Headquarter)



Chemistry and scale-up  
Analytics  
Physics (vapor/solution)  
Application (vapor/printing)

England



Solution processable OLEDs  
Ink Formulation  
Printing evaluation

South Korea



Chemistry  
Analytics  
Physics/Application (2014)

Japan



Ink Formulation and scale-up  
(2014)

Taiwan



Physics/Application (end 2013)

# We Make Communication Visible™

**Thank you for your kind attention.**

A large, abstract graphic in the bottom right corner consisting of several overlapping, curved, blue shapes that resemble stylized leaves or petals, creating a sense of depth and movement.